



LG V20 Volume Button Replacement

This guide explains the steps required to remove the volume button from the LG V20.


Written By: Garrett Janney



INTRODUCTION

Exposure to dirt or the shock of dropping a phone can damage volume buttons and cause them to become unresponsive. This guide will lead you through all the steps required to get your LG V20's volume button out of the phone and ready for replacement.

Step 1 — Battery



- Flip over the phone and lift the back cover off while pressing the small button on the bottom left side.

Step 2




- Place your thumb along the bottom of the battery and pull up to remove the battery.

Step 3 — Midframe



- Use a screwdriver to remove the twenty-one 4mm Phillips #00 screws attaching the back cover to the motherboard.

Step 4




- Remove the top and bottom frame sections by applying force to one side of the frame until it pops off.
- ⓘ The covers are held together very firmly by plastic clasps, so do not be afraid to apply pressure.

Step 5





- To remove the loudspeaker at the bottom left of the device, use the blue plastic opening tool to gently pry up on the corner of the speaker.

Step 6



- Using a blue plastic opening tool, gently pry the cover up by pushing the tool down towards the device.
- Repeat this process in various locations until the cover pops off and can be removed.

Step 7 — Volume Button



- Locate the volume button on the left edge of the phone.
- Use a blue plastic opening tool to slide the volume button out of the phone.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-16 01:29:40 PM.